



NOTES:

1. FILTER FABRIC SHALL BE PLACED UNDER ROCK TO STOP MUD MIGRATION THROUGH ROCK.
2. FILTER FABRIC IS NOT REQUIRED UNDER WOODCHIPS.
3. ENTRANCE MUST BE MAINTAINED REGULARLY TO PREVENT SEDIMENTATION TRACKING.



STANDARD DETAILS
CONSTRUCTION ENTRANCE
ROCK AND WOODCHIP

COTTAGE GROVE, MINNESOTA

LAST REVISION:
JAN 2014

PLATE NO.
ERO-12